

Scale&Print SDK-Android Access Guide

- I. Role of Access Package
- II. Scope of Model Support
- III. SDK Usage Evaluation
- IV. SDK access
 - 1. development Guide

I. Role of Access Package

provide a connection suitable for Android platform, so that customers can connect our load cell and printer to the software system by adjusting the Android API I provided by me. By adjusting the connection we provide, customers can realize the seamless docking between the printer and the software system.

II. Scope of Model Support

no.	Model	firmware Version
01	C- L9A	all versions

note: Other machine models or equipment with firmware versions outside the model range will not be held.

III. SDK Usage Evaluation

1. If you need to access the evaluation, you can first experience the SDK DEMO. The experience process is as follows:
 - a. Open the Android studio editor
 - b. Import SDK Demo
 - c. Compile
 - d. Real machine compilation

IV. SDK access

1. development Guide

if you are a developer, the following steps can help you easily connect to the SDK: ●View SDK DEMO: Use Android studio to open the SDK DEMO. Refer to the SDK DEMO in the SDK DEMO to learn how to use the SDK correctly.

- view connection File: view the SDK connection description file to obtain detailed connection description.

- before developing, please be sure to carefully refer to the "Instructions for Use" in the connection file so as to understand the instructions for the process configuration, permission configuration and device setting.

- SDK adjustment process: connect the file sample demo section it includes the SDK adjustment process on the Android side. Please study it carefully. This is often important for smooth connection.

Related notes: ● Other related issues can refer to the notes document

if you need further assistance or have any questions, please feel free to contact our support team, who will be happy to provide you with support and guidance.